
Con1
Z80_BUS
Default port 32 (0x20) used for en.
Other spare ports hidden under
138. Unlikely to be needed unless
Port 32 clashes with other device
J1
Conn_01x06
J2
Conn_01x01
U1
74HCT138
U2A
74HCT04
U3
82C55A
U2D
74HCT04
U2G
74HCT04
J3
Conn_02x20_Odd_Even
J4
Conn_02x22_Odd_Even
D4
LED
JP1
Jumper
J5
Barrel_Jack_Switch
VCC
GND
Sheet: /
File: RC2014 IDE 8255.sch
Title:
Size: A4
Date:
Rev:
KiCad E.D.A. kicad 5.1.5-52549c584ubuntu18.04.1
Id: 1/1